

# HIDKITPROS.COM

## Dodge Ram 2500/3500 20" Light Bar Mount – 70568

**Notice:** Designed to fit TOTRON 20" Dual ROW LED light bar kit SKU: TLB3120. Compatible with other 20" aftermarket lights measuring 22-3/16" from mounting point to mounting point.

Required Tools:	Kit Contents:
• 18mm Socket	• 2x Brackets

### -INSTALLATION INSTRUCTIONS-

1. Using a 18mm socket remove the four factory bolts securing each tow hook to the frame.
2. Place the bracket behind each tow hook (with the light tab to the inside) and insert the tow hook back onto the truck using the factory bolts. Hand tighten. See **Photo 1**.
3. Install the 20" light bar between the brackets and secure to brackets with the supplied bolt. See **Photo 2**.
4. Tighten tow hook bolts with a 18mm socket.
5. Wire the light with the supplied light instruction sheet.

